


④ Unit selecting method (When DC voltage or DC current is specified.)(\*5)




Note: The unit of thermocouple and RTD is decided by input selection.

⑤ Sensor correcting value setting(\*6)

- Settable:  $\pm 10.0\%$  of scaling range span


Notes: 1. The decimal point place is as specified.  
2. The unit is as selected in unit selection.


⑥ Square root extraction function designating method (\*7)




1-11 Communication parameter setting (Option: C, C5)

- Set the communication parameters (Transfer rate, Data length, Parity, Stop bit and Instrument number) in this item.
  - With this mode, set the parameters in the status the running mode [Stopping].
  - Refer to the "Key functions" (page 10) for the key operation such as the setting value setting.
- Communication parameter setting









Note: When controlling by the communication line, the instrument numbers of the HCD-130s are settable from 0 to 223, however, it does not mean connectable number of units, but the settable instrument numbers. Connectable HCD-130s are maximum 31 units.

▪ RS-232C communication line



▪ RS-485 multiple-down connecting communication line




Communication converter [IF-100-C5] is available, separately sold.

1-12 Cascade parameter setting (Option: CC)

- Set the parameters on the cascade slave side [Proportional band (P), Integral time (I), Derivative time (D), Anti-reset windup (ARW), PID auto-tuning and PID auto-tuning bias]. Set the only necessary items.
- To set the Integral time (I) and Derivative time (D), the proportional band (P) must be set.
- To set the Anti-reset windup (ARW), the Proportional band (P) and Integral time (I) must be set.
- When the proportional band is set to the value excepting 0.0, it can adjust the offset only when the integral time (I) is set to 0. (\*1)
- Refer to the "Key functions" (page 10) for the key operation such as the setting value setting.

● Cascade PID parameter setting



※45


※46

※47

※48

※49

※50



▪ Offset adjustment (\*1)

[Derivative time (D) setting mode]

\* PID PARAMETERS \*  
POFFS= 1.5°C

Adjust the slave Proportional band offset (difference between SV and PV) with "△, ▽ and [FAST]" keys. [Settable from - Prop. band to + Prop. band] [Factory adjusted as 0]

[Sub-proportional band (P) setting mode]

▪ Slave PID auto-tuning designating method (\*2)

[Slave Anti-reset windup (ARW) setting mode]

\* CASCADE PARAs \*  
AT=START STOP

Select "START" or "STOP" with "△ or ▽" key.


[Selected side flashes.]


[Slave PID auto-tuning bias setting mode]

1-13 Cascade scale setting (Option: CC)

- Set the Cascade slave side scale setting [Input range, Unit, Scaling low limit, Scaling high limit, Setting value low limit, Setting value high limit].
- All items are not required to set, set the only necessary items.
- Refer to the "Key functions" (page 10) for the key operation such as the setting value setting.

● Cascade scale setting





- (\*1) Slave setting value low or high limit settable range

From  $-\text{[(Slave scaling high limit setting value) - (Slave scaling low limit setting value)]} \times 10 + \text{(Slave scaling low limit setting value)}$   
to  $\text{[(Slave scaling high limit setting value) - (Slave scaling low limit setting value)]} \times 10 + \text{(Slave scaling high limit setting value)}$

- Notes:
- The unit is selected as specified in the slave unit selection.
  - (\*2) Low limit setting value of slave side rated input
  - (\*3) High limit setting value of slave side rated input




1-14 Other functions


\*In this item, the basic functions to use the HCD-130 are selected, adjusted or set. The functions are: "Running mode selection Running or Stopping", "Remote/Local selection", "Setting value lock selection (When Security function [Option: SE] is applied, selection by the function)", "LCD multi-display contrast adjustment", "PID auto-tuning bias value setting", "Remote bias value setting", "Display contents when stopping status is selected", "Instrument power supply frequency selection" and "Control mode, Direct/Reverse selection".

- Notes: 1. If the option Security setting (Option: SE) is applied, the Setting value lock function selection is not called. In that case, set the Setting value lock function by the Security setting (Option: SE).  
 2. All items are not required to select, adjust or set, however, the functions ["Selection of running mode, Running or Stopping", "Instrument power frequency selection, 50Hz or 60Hz" and "Control action, Direct or Reverse selection"] should be confirmed.

• Refer to the "Key functions" (page 10) for the key operation such as the setting value setting.

■ Setting flow chart





Select 7 kinds of lock functions with ", " keys. (See page 53)  
This function is not called when the option SE is specified.  
[Factory adjusted as free]

Adjust the contrast of LCD multi-display with ", and " keys.  
[Factory adjusted as 40%]

Set the PID auto-tuning bias value with ", and " keys.  
[Factory adjusted as 0]

Set the Remote bias value [Option:E] with ", and " keys.  
[Factory adjusted as 0]


Select the indication of PV display when [Stopping] status with ", or " keys. (See page 53, below \*2)  
OFF ⇔ Process variable ⇔ None  
[Factory adjusted as OFF]  
● This manual is described as OFF.

Select the instrument power frequency with ", " keys.  
[Factory adjusted as 60Hz]

Select the Direct action or Reverse action with ", " keys.  
[Factory adjusted as Reverse]

\* Security setting mode  
This function is not called when Option [SE] is not specified.  
[See page 54 to 56 for the detail.]

● Setting value lock function selecting mode (\*1)



Control output OFF function (\*2)

- OFF : It stops the control output, and indicates "OFF" on PV display.
- PV : It stops the control output, and indicates the process variable on PV display.
- None: It stops the control output, and PV display indicates nothing. Only the back-light is lit on LCD.

● Security function (Option: SE)

It is the setting value lock function to change the lock status applying the registered security code (4-digit numerals).


With this function, 10 kinds of security code and 6 kinds of lock status (hereafter security level) can be registered at will. Therefore, the operation to meet the level of the security code holder can be performed, and setting contents are secured from wrong operation.

▪ How to set the security code.

Call the security setting mode by 1-14 Other functions.

Then, set the security level and security code respectively to the Set No. 0 to 9 in security setting mode.

- After the power is turned on, the security level will be as registered by security code 0000. If security code 0000 is not set, after the power turned on, the security level will be selected as 0.
- When different security level is registered to the same code, the level of the smaller Set number has priority.
- In case the option [SE] is not specified, this mode will not be indicated.



- Notes:
1. Move the flash and set to the Set No. with "[MODE] or [DISP] key.
  2. The setting is registered if pressed "[ENT]" key, or when moved to another item.
  3. Set the security level and security code with "[▲] and [▼]" keys.
  4. Registered security code and the level should be kept a record for the memory without fail.

**CAUTION:** WHEN SETTING THE SECURITY LEVEL, 1 OR MORE OF LEVEL 5 MUST BE SET AT LEAST. IF THE SECURITY LEVEL 5 IS NOT SET, ANY LOCK STATUS (SECURITY LEVEL 0 TO 4, DIFFERENT FROM THE SECURITY CODE SETTING STATUS) WILL BE APPLIED AND THE LOCK CANNOT BE RELEASED.

- Factory adjusted as follows:

Set No.	Security level	Security code
0	5	0000
1 to 9	0 to 0	9999 to 9999

- Security level

Security level No.	Lock status (Refer to page 14 for the items 1-1 to 1-14)
0	All setting items are unchangeable.
1	1-1 Main setting value setting to 1-14 Other function are unchangeable. (Excepting 1-2 Setting value memory No. selection.)
2	1-3 PID parameter setting to 1-14 Other function are unchangeable.
3	1-4 Alarm setting value setting to 1-14 Other function are unchangeable.
4	1-5 Alarm output parameter setting to 1-14 Other function are unchangeable.
5	All setting items are changeable.

- How to operate the Security function

In [Running] or [Stopping] mode, if **[MODE]** key is pressed for approx. 3 seconds, LCD multi-display turns to Security code input mode.

- Security code input mode display

Your Security  
Code = 0 0 0 0

In this display, input the code registered in Security code setting mode with "**[▲]**", "**[▼]**" and "**[FAST]**" keys, and if "**[ENT]**" key is pressed, LCD multi-display changes to [Running] or [Stopping] mode.

After selected the level and code, the level is applied to the code, and the operation to meet the level of the security code holder can be performed.

If the security code not registered is selected, the security level becomes 0. When the Security code input mode is called, the security code is always displayed as 0000.

The security levels changed by security code input mode are maintained until the level is changed in the security code input mode or the power is turned on again.

[Setting example]

When the setting is assumed as follows:

Set No.	Security level	Security code
0	5	1993
1	3	0202
2	3	1791
3	2	1791
4	4	4571
5	2	5000
6	1	0000
7	0	9999
8	0	9999
9	0	9999

In this case, the security code 0000 is set to the security level 1, therefore, after the security setting is completed or the power is turned on, the security level becomes 1.

To make the security level to 4, input the security code 4571.

If the code not registered to the security code setting mode is input, the security level becomes 0.

Further, if input the code to 1791, the level 3 registered in Set No. 2 will be selected (Smaller Set No. has priority).

(2) Running mode

2-1 PID auto-tuning designation


- It designates start or stop of the PID auto-tuning.
- During running mode [Running], if "AT" key is pressed for approx. 1 sec., the PID auto-tuning indicator (Yellow LED) blinks, and the controller starts tuning. When the tuning is completed, the indicator turns to unlit.  
To cancel the PID auto-tuning on its halfway, press "AT" key again for approx. 1 sec., then, the indicator (Yellow LED) turns to unlit, and releases the tuning.
- \* If the PID auto-tuning is cancelled on its halfway, proper PID parameters cannot be set, but returns to their former parameters.
- \* The front key setting cannot be performed during auto-tuning, however, remote setting [option code: E] or Setting value memory number [option code: SM] must not be changed during auto-tuning, or proper PID parameters will not be set.

2-2 Manipulating value manual setting

- It sets the manipulating value by manual.
- During running mode [Running], if "AUTO MAN" key is pressed for approx. 1 second, the mode is changed to manipulating value manual setting (\*1), and the manipulating value can be set with "▲", "▼" and "FAST" keys.  
If pressed "AUTO MAN" key again for approx. 1 second, the mode turns to running mode [Running].
- Settable range:
  - 0 to 100.0%
  - 5.0 to 105.0% (Current output)
  - 100.0 to 100.0% (Heating and Cooling control output (Option: D□)  
In case the main output is DR (relay) or DS (SSR drive).
  - 105.0 to 105.0% (Heating and Cooling control output (Option: DA)  
In case the main output is DA (current).

- Notes:
- It has bidirectional balanceless bumpless function, and when changed the control from automatic to manual (vice versa) it prevents the manipulating value from sudden change. If the dead band is set, the balanceless bumpless function at Sub-output (Cooling) side does not work, during Heating and Cooling control and when changed the control from automatic to manual.
  - When changed the control from automatic to manual, it makes the manipulating value at which automatic control is operated to the initial value of manual operation.
  - When changed the control from manual to automatic, it makes the manipulating value at which manual control is operated to the initial value of automatic operation.


● Manual manipulating value setting (LCD multi-display)




2-3 Manipulating value indication change (LCD multi-display)

• During running mode [Running], LCD multi-display can be changed with "DISP BM" Key.

1. Change of manipulating value indication (Main and Sub). (Option code: D□)




2. When cascade control



2-4 Delayed starting timer setting

- It does not start the control instantly after the power supply is turned on, but it starts the control after the preset time has elapsed.
  - In running mode, if "SET RST" key is pressed for approx. 3 seconds, delayed starting timer will be selected. Set the delayed starting time with "△", "▽" and "FAST" keys. Then, if "ENT" key is pressed, the timer starts. LCD multi-display shows the rest time to start the control. Settable from 00:00 to 99.59 (maximum, 99hours 59minutes) [To interrupt the time, press "SET RST" key again, then it returns to running mode.]
- Indications of the Process variable (PV) and Setting value (SV) are the same as the indication [Stopping] status.






**7. Running**

After completion of the mounting to the control panel and wiring connections, start running in the following manners:


- ① Confirm that the conditions to use the HCD-130 (Item 1-14 Other function) are set correctly.
- ② Set the necessary items to control, referring to the section "6. Operation".
- ③ Turn the control circuit power ON.
- ④ Controller starts the control action so as to maintain the controlled object at the setting value. However, if the control action is set to [Stopping], it does not start the control action. To start the control, select [Running] in the item 1-14 Other function (page 51).

■ Displays and indicators when Running



● Each indicator is lit or unlit according to the controlling status.

● Indication of LCD multi-display




Note: Indicating contents of the LCD differ from the option applying status. See page 57 to 58 for the detail.

■ Battery change for the memory-card (Option: DM)

- Memory-card is equipped with a battery for test, and it may have been consumed. Therefore, it has to be exchanged to the attached one when unpacked.
- Unscrew the battery cover screws with small phillips screwdriver enclosed, and remove the cover to take the old battery off.
- Set the new battery (Lithium battery, CR1616) setting + side up into the memory-card, and put the battery cover fastening with the screws. 《Make the battery polarity sure.》

- Notes:
1. Battery life is approx. 2 years at room temperature. (Old battery must be removed from the memory-card.)
  2. IF THE BATTERY IS REMOVED FROM THE MEMORY-CARD, ALL OF THE DATA MEMORIZED INTO THE MEMORY-CARD WILL BE GONE OUT, WHEN CHANGING THE BATTERY, THE DATA SHOULD BE MEMORIZED TO THE HCD-130, AND THEN CHANGE THE BATTERY.
  3. Do not bend the card, and avoid from shock.
  4. Avoid the card from high temperature, high humidity and the location exposed to direct sunlight.
  5. Do not touch the terminal of the card, and do not put the things into the terminal.




- Set the battery making the + side up into the memory-card battery holder.

2. Running (Cascade control [Option code: CC])

One unit of HCD-130 allows to perform the cascade control. Two systems (Input 1 for the primary controller [master] and input 2 for the secondary controller [slave]) are provided to control one process, and higher control can be achieved.

● Cascade control



- |                                      |                                     |
|--------------------------------------|-------------------------------------|
| SV (M): Master main setting value    | SV (S): Slave main setting value    |
| PV (M): Master input value (input 1) | PV (S): Slave input value (input 2) |
| PID (M): Master PID value            | PID (S): Slave PID value            |
| AT (M): Master PID auto-tuning       | AT (S): Slave PID auto-tuning       |
| MV (M): Master manipulating value    | MV (S): Slave manipulating value    |
- (The slave setting value corresponds to 0 to 100% of this value.)

● Operations by auto-tuning

1. Decision of slave side PID value
  - 1.1 Set the slave high and low limit setting values to the same value as desired to control.
  - 1.2 Perform the slave PID auto-tuning. (See page 48)
2. Decision of master side PID value
  - 2.1 Set the slave high and low limit setting values to each desired value. (Above range corresponds to 0 to 100% of the master manipulating value. This range is required to decide examining the disturbance effects.)
  - 2.2 Set the master main setting value (desired value).
  - 2.3 Press **[AT]** key to perform the master PID auto-tuning. (See page 47 to 50)

8. Specifications

8.1 Rating

① Rated scale

Input	Scale range		Resolution
K	0 to 1370.0°C	0 to 2500.0°F	0.1 °C (°F) *1
J	0 to 1000.0°C	0 to 1800.0°F	0.1 °C (°F) *1
R	0 to 1760.0°C	0 to 3200.0°F	0.1 °C (°F) *1
S	0 to 1760.0°C	0 to 3200.0°F	0.1 °C (°F) *1
PL-II	0 to 1390.0°C	0 to 2500.0°F	0.1 °C (°F) *1
B	0 to 1820.0°C	0 to 3300.0°F	0.1 °C (°F) *1
E	0 to 1000.0°C	0 to 1800.0°F	0.1 °C (°F) *1
T	-270.0 to 400.0°C	-450.0 to 750.0°F	0.1 °C (°F) *1
W/Re5-26	0 to 2315.0°C	0 to 4200.0°F	0.1 °C (°F) *1
N	0 to 1300.0°C	0 to 2300.0°F	0.1 °C (°F) *1
Pt100	-200.0 to 850.0°C	-200.0 to 1500.0°F	0.1 °C (°F) *1
DC	-1999.9 to 2000.0		1 *2

\*1: Changeable to 1

\*2: Decimal point position is changeable

② Input Thermocouple K, J, R, S, PL-II, B, E, T, W/Re5-26 and N (JIS, IEC)

Input impedance : 1MΩ or greater

Signal source resistance effect: 0.5 μV/Ω

When input burns out : Upscale

(Downscale is applicable as well)

RTD Pt100 3-wire system (JIS, IEC)

Allowable input lead wire resistance: Per wire 5Ω or less

When input burns out : Upscale

DC current 0 to 20mA<sub>dc</sub>, 4 to 20mA<sub>dc</sub>

Input impedance : 250Ω

When input burns out : Downscale

DC voltage -10 to 10mV<sub>dc</sub>, 0 to 10mV<sub>dc</sub>, 0 to 100mV<sub>dc</sub>, 0 to 1V<sub>dc</sub>, 0 to 10V<sub>dc</sub>,  
-1 to 1V<sub>dc</sub> and 1 to 5V<sub>dc</sub>

Input impedance : 1MΩ

Allowable input voltage: 15V or less

When input burns out : mV input, Upscale

(Downscale is applicable as well)

V input, Downscale

③ Supply voltage 100 to 240 (85 to 264)V<sub>ac</sub>, 50/60Hz

8.2 General structure

- ① External dimension     96(H)×96(W)×177(D)mm
- ② Mounting method       Flush
- ③ Case                    Incombustible resin, Color: Black
- ④ Panel                   Incombustible resin, Color: Black

8.3 Indicating structure

- ① Display                 Process variable(PV): 7-segment red LED display 5 digits  
size 14.3(H)×8(W)mm

Setting value (SV): 7-segment green LED display 5 digits  
size 10(H)×5(W)mm

Setting value memory  
number indication : 7-segment green LED display 2 digits  
size 8(H)×4(W)mm

Character indication: 16-digit×2-line LCD with Backlight

- ② Action indicator
 

When main control output ON	: Green LED (C1)	lights
When sub-control output ON	: Yellow LED (C2)	lights (Option)
When alarm 1 action output ON	: Red LED (A1)	lights
When alarm 2 action output ON	: Red LED (A2)	lights (Option)
When alarm 3 action output ON	: Red LED (A3)	lights (Option)
When alarm 4 action output ON	: Red LED (A4)	lights (Option)
When sensor burns out	: Red LED (SB)	lights
When remote operation	: Red LED (REM)	lights (Option)
When manual control	: Red LED (MAN)	lights
When automatic control	: Green LED (AUTO)	lights
When auto-tuning performing	: Yellow LED (AT)	blinks

8.4 Setting items

- ① Main setting     : Main setting.
- ② Setting value  
memory selection: Setting value memory number selection.
- ③ PID parameter  
setting            : Proportional band         \*3         Integral time                 \*3  
                    Derivative time         \*3         Anti-reset windup (ARW) \*3  
                    Proportional band offset \*3  
                    Sub-proportional band (Option)     Sub-derivative time (Option)
- ④ Alarm setting    : Alarm 1, Alarm 2 (Option), Alarm 3 (Option) and Alarm 4 (Option)
- ⑤ Alarm action  
parameter  
setting            : A3 action method selection (Option)  
                    A4 action method selection (Option)  
                    Alarm 1 hysteresis setting  
                    Alarm 2 hysteresis setting  
                    Alarm 3 hysteresis setting  
                    Alarm 4 hysteresis setting